

# Exterior Calculation

To determine total square footage needed, use the directions to calculate the area of each part of the house on which Drain-Plane is to be installed. Add the square footage for all parts together for the total.

Front Wall	Multiply the width by height (C x D)
Side Wall	Multiply the width by height (E x F)
Garage	Multiply the width by height (A x B)
Gabel	Multiply the width by height (G x H) and divide by 2
Dormer	Multiply the width by height (I x K) Multiply the width by height (I x K) and divide by 2 Add the numbers together

